



USER'S MANUAL



STANDARD KEYBOARD

STANDARD 502

Congratulations on purchasing the TM REAL-EL keyboard!

Please read this User's Manual before using the unit and retain this User's Manual in safe place for future reference.

COPYRIGHT

© 2017. ENEL GROUP OU.

This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

PACKAGE CONTENTS

- Keyboard – 1 pc
- User's Manual – 1 pc
- Warranty card – 1 pc

SPECIAL FEATURES

- Ergonomic design
- Standard layout
- High-quality membrane
- Comfort, quiet and clear keystroke
- USB Interface

SYSTEM REQUIREMENTS

- OC Windows XP/Vista/7/8/10
- Free USB port.

INSTALLATION

- Connect the keyboard to an available USB port of your PC.
- Installation of the keyboard is automatic after its connection to a PC USB port.

TROUBLESHOOTING

Problem	Solution
The keyboard is not working.	<ol style="list-style-type: none"> 1. Disconnect the keyboard from your PC and check connector pins for possible damage. If there is no external damage found and connector pins are OK, connect the keyboard to your PC again. 2. We recommend to address the nearest authorized service center.

TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Keys layout	103
Keyboard layout	Rus/Ukr/Eng
OS compatibility	Windows XP/Vista/7/8/10
Interface	USB
Error-free running time	more than 20,000,000 strokes
Dimensions (W × H × L), mm	430 × 20 × 135
Weight, g	420

Notes:

- **Technical specifications given in this table are supplemental information and can not give occasion to claims.**
- **Technical specifications and package contents are subject to change without notice due to improvement of TM REAL-EL production.**



Model: **Standard 502**

Manufacturer: ENEL GROUP OU, Jõe tn 5-39, Tallinn, Harjumaa 10151, Estonia.
Made in China.

© **Registered Trademark of ENEL GROUP OU. Estonia.**