
REAL-EL

USER MANUAL



ELECTRIC HEATED CLOTHES AIRER

W–7050

Congratulations on your purchase of TM REAL-EL products!

COPYRIGHT
© 2026 ENEL GROUP OU.
This Manual and information contained in are copyrighted. All rights reserved.

TRADEMARKS
All trademarks are the property of their legal holders.

PACKAGE CONTENTS
- Electric heated clothes airer – 1 pc
- User manual – 1 pc
- Warranty card – 1 pc

SPECIAL FEATURES
- Lightweight
- Rust proof
- 18 heated bars
- 10 kg drying capacity
- Folded design
- Cost efficient energy saver


SAFETY AND CAUTIONS
- Stop using when the product cover or heating tube damaged.
- Connect the plug to mains with earthing only to avoid the risk of electric shock.
- Start power only after the product is clean and installation finished properly.
- Do not operate this appliance with a damaged cord, plug, or after the appliance malfunctions or has been damaged in any manner.

ASSEMBLY AND OPERATION


WARNING: The product must be assembled before first use.

1. Place the main section (4) upside down on the floor, folding the hanging sides (3). The inner (2) and outer (1) sliding fixing brackets on the main section should face upwards for easy fixing (see fig. 1).


Note: 4 spare fixing brackets are fixed to the main section for replacement in case of damage.



Identify the outer half of the support leg (5) and fix it to the outer sliding fixing brackets (see fig. 2).




Fix the inner half of the support leg (6) to the inner sliding fixing brackets (see fig. 3).




INSTALLATION

1. Lift the main section horizontally (see fig. 4).




2. Unfold and fully extend the support leg (see fig. 5).

5




3. Unfold the hanging sides (see fig. 6).

6



4. Make sure that the product is placed on a flat and stable surface, close to a power socket.

7



GETTING STARTED

• Connect the plug to the mains socket. Switch ON the appliance using the power switch (7). It takes approximately 15 minutes for the product to reach the optimum temperature.
• Start loading from the main hanging section before loading the hanging sides. To ensure stability, make sure that the product is evenly loaded with laundry. The loading capacity is 0.8 kg for each hanging side and 10 kg for the product as a whole.
• Do not overload the product.
• Do not use the product without a load.

TECHNICAL SPECIFICATIONS

Parameter	Value
Heater type	electric
Total quantity of heating tubes	18
Quantity of tubes of the main section	8
Quantity of tubes of the additional sections	10
Temperature control	45 - 55 °C
Maximum power	230 W
Connection plug	CEE 7/7
Power cable length	2 m
Installation type	floor-standing
Product material	Aluminum
Protection	IPX1
Power supply	230/50 V/Hz
Product dimensions	1480 × 540 × 1090 mm
Product dimensions when folded	1160 × 60 × 540 mm
Color	grey
Weight	2.5 kg

Notes:
• Technical specifications given in this table are supplemental information and cannot give occasion to claims.
• Technical specifications and package contents are subject to change without notice due to the impro- vement of REAL-EL production.

Manufacturer: ENEL GROUP OÜ, Harju maakond, Rae vald, Jüri alevik, Aruküla tee 55a, 75301, Estonia.
® Registered Trademark of ENEL GROUP OÜ. Estonia.