# REAL-EL

## **USER'S MANUAL**



WIRELESS OPTICAL MOUSE

RM-325 WIRELESS

## Congratulations on purchasing the TM REAL-EL PC mouse!

Please read the following instructions carefully before connecting, operating or adjusting this product. Besides, please keep this Manual in a safe place for future reference.

#### COPYRIGHT

© 2015. ENEL GROUP OU. This Manual and information contained in it are copyrighted. All rights reserved. All trademarks are the property of their legal holders.

#### NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information in this Manual is given on "as is" terms. The author and the publisher do not bear any liability to a person or an organization for loss or damage which has arisen from the information contained in this Manual.

#### CONTENTS

DNIENIS	
1. SPECIAL FEATURES	
2. PACKAGE CONTENTS	2
3. SYSTEM REQUIREMENTS	2
4. DESCRIPTION	3
5. INSTALLATION	3
6. TROUBLESHOOTING	6
7. TECHNICAL SPECIFICATIONS	6

## Wireless Optical Mouse

#### 1. SPECIAL FEATURES

- · Power saving wireless technology
- · Stylish ergonomic design
- . Effective on most surfaces
- USB nano receiver included (range up to 10 m)
- · DPI resolution switch
- Resolution 800/1200/1600 dpi
- USB interface
- · Powered by 2 AAA batteries
- · Long life battery-fed operation
- Drivers installation is not required for Windows XP/Vista/7/8

#### 2. PACKAGE CONTENTS

- Optical mouse 1 pc
- 2.4 GHz USB nano receiver 1 pc
- 1.5V DC AAA batteries 2 pcs
- User's Manual 1 pc
- Warranty card 1 pc

#### 3. SYSTEM REQUIREMENTS

- Windows XP/Vista/7/8.
- Free USB port.

#### 4. DESCRIPTION

- Scroll wheel
- Opi resolution switch
- Power switch
- Optical sensor
- S Battery compartment
- O Nano receiver
- USB connector



Fig. 2. Bottom view



Fig. 1. Top view



Fig. 3. Nano receiver

## 5. INSTALLATION

- Open the cover of the mouse battery compartment **3**, insert 2 AAA 1.5V DC batteries into the battery compartment matching the polarity, and close the cover of the battery compartment (see Fig. 4).
- Connect the included nano receiver 6 to a free PC USB port (Fig. 5).

Turn on the mouse with the on/off switch (the ON position). To activate
the mouse, press any button of the mouse or turn the scroll wheel. If the
mouse is connected correctly, it will turn on automatically.




Fig. 4. Battery installation



Fig. 5. Receiver connection

- After finishing work turn off the mouse with the power switch (the OFF position). After this, you can pull out the receiver from the PC USB port and insert it into the mouse (Fig. 6). When using the receiver again, pull it out from the mouse (Fig. 7) and connect it to the PC USB port again.
- Do not place the receiver into a confined metal space (table drawer, box, safe), as a metal screen does not transmit radio signals.
- If the batteries run down, the mouse works in jerks. It means that the batteries should be replaced with new ones, as it is shown in Fig. 4. Always install only identical new batteries.



Fig. 6. Fitting the receiver into the mouse case



Fig. 7. Extraction of the receiver from the mouse case

# 🛕 Important -

➤ This device meets the highest standards of energy conservation. Use the switch 0 on the bottom of the mouse to switch it on/off – it will help you extend the mouse battery life.

#### 6. TROUBLESHOOTING

Problem	Solution
The mouse does not work.	Make sure that the nano receiver has been inserted into the USB port and its distance to the mouse is less than 10 m.     Check whether the batteries have been installed correctly.     Check if the batteries have run down, replace the batteries with new ones if necessary.     Address nearest authorized service center.

#### 7. TECHNICAL SPECIFICATIONS

7. TECHNICAE OF ECH TOATIONS		
Parameter	Value	
OS compatibility	Windows XP/Vista/7/8	
Type of mouse	wireless 2.4 GHz	
Resolution, dpi	800/1200/1600	
Q-ty of buttons	2 + 1 (scroll wheel)	
Interface	USB	
Battery type	2 × AAA 1.5V DC	
Dimensions, mm	105 × 70 × 36	
Weight, g	83	

## Notes:

- Technical specifications given in this table are supplemental information and cannot give occasion to claims.
- Technical specifications and package contents are subject to change without notice due to improvement of REAL-EL production.



Model: RM-325 Wireless

Manufacturer: ENEL GROUP OU, Joe tn 5-39, Tallinn, Harjumaa 10151, Estonia.

Made in China.

® Registered Trademark of ENEL GROUP OU. Estonia.